

How do I license the gateway

License the gateway

It is recommended for all the gateway models to use online licensing to activate the license. To do online licensing, make sure the gateway has Internet connection and do the following:

1. Login to Admin GUI. There should be a red warning box shown on Status page.



2. Click button "Activate License". Gateway will be automatically licensed.


License Information

License Activated	Yes
License	2000 devices
Storage Limit	2000 devices
Hardware Serial Number	44WHD2S
Software Serial Number	02-6666-IG300-E2000-0001035-02000-02000


Additional Note:

Common Issues of failed to license online:

- WAN Interface setting is not configured properly for Internet Connection
- DNS server configuration issue
- Upstream network firewall is not allowed for web connection (port 443,80)



- System has reached the license activation limit



If the online licensing does not work, you can activate the license manually. Please contact ANTLabs support for assistance.